

## LED stroboscope flash light VT105



Monitoring units can be used.  
Requires for lights alarms.  
12V LED strobe light for warnings and alarms.  
Can be used with monitoring units by connecting it to 12V outputs.

|                               |  |
|-------------------------------|--|
| <b>Dimensions</b>             | 73 X 45mm, Cable 2 m   |
| <b>Weight</b>                 | 110 g  |
| <b>Power Input</b>            | 12V, 120mA   |
| <b>Power Consumption</b>      | 1 Watt   |
| <b>Operating Temperature</b>  | Min. -50° C - Max.+105° C  |
| <b>Mounting</b>               | Wall Mount with Dowels or Sticker  |
| <b>HS-Code</b>                | 8531 10 300  |
| <b>Package includes</b>       | 12V LED Device With 2m Cable, 2 Back Panels, X2 M3 Screws, X2 Dowels, X2 Screws For Dowels                           |
| <b>Special features</b>       | Flashing frequency: 90/min<br>IP Rating Standard: IP54<br>Type: LED security alarm, Colour: Red<br>Material: Plastic |
| <b>Inputs Terminals</b>       | 2-Wire cable   |
| <b>Outputs Terminals</b>      | LED Flashing Light Source  |
| <b>Satelco Article number</b> | <b>11189</b>   |

All specifications are subject to change without notice or obligation to provide such changes to previous customers. The information and specifications published hereunder are current as of the date of publication of this document. We reserve the right to change specifications without prior notice. [www.satelco.ch](http://www.satelco.ch)

\*Warranty Ex Works, normally 24 months, to be determined at time of order. Information is current at the time of publication. Specifications are subject to change without notice. / NOTE: Internal connections refer to connections inside the equipment, usually on a header. External connections refer to connections outside the enclosure. Once the unit is mounted, only the connections designated as "accessible from the front" are accessible to the customer.