

Extensions & information modules



2N add-on 8 x 1 buttons
Add-on module with 8 buttons,
LED lighting



2N add-on 8 x 2 buttons Add-on module with 16 buttons, LED lighting



2N Infopanel
Without button function,
LED lighting

Weather protection & assembly frame



2N in-wall housing UP for 1 module
In-wall housing for indoor installation



2N in-wall housing with UP weather protection frame for 1 module
In-wall housing for outdoor or indoor installation



2N weather protection frame AP for 1 module
Roof for outdoor installation



2N in-wall housing UP for 2 modules
In-wall housing for indoor installation



2N in-wall housing with UP weather protection frame for 2 modules
In-wall housing for indoor or outdoor installation



2N weather protection frame for 2 modules
Roof for outdoor installation


Accessories



2N additional button with nameplate - single
Additional button with nameplate
(Vario 1 & 3 buttons)



2N additional button with nameplate - double
Additional button with nameplate
(Vario 3 x 2 buttons)



2N Infopanel cover
Cover with nameplate for information panel

Power supply unit/network accessories



DIN housing 12 V DC power supply
12 V DC / 1A or 12 V DC / 2A power supply unit

Additional switching contact / electrical door lock



2N additional switching contact
Mounting set for 2N Vario analogue basic module,
2nd relay (dry contact)

In-built colour CCD camera for 2N Vario analogue



The camera can be built in any basic unit. In the case of poor light, the camera switches into the monochrome mode automatically. Supplementary infrared light. Horizontal/vertical tilting option

All specifications are subject to change without notice or liability to provide changes to prior purchasers. Information and specifications published here are current as of the date of publication of this document. We reserve the right to change or modify specifications without prior notice. www.satelco.ch

* Warranty ex works, normally 24 months, fixed at order. Information is current as of the date of publication. Subject to errors and modifications. / NOTE: Internal connections refer to connections inside the unit, generally mounted across a pin-header. External connections refer to those outside the box. Once mounted, only connections described as "front accessible" can be accessed by the customer.